




TX MR6K-48

KERNEL ITEM NO. 161202

Kernel Edtion 1.0
Mar.2008



Spare Parts List

ITEM	DESCRIPTION	QTY
1B	Table	1
2B	Retaining ring	6
3B	Locking nut	1
4B	Oil pipe connector	3
5B	Branch inlet pipe	2
6B	Oil pipe connector	2
7B	Oil supply fitting	1
8B	Nut	4
9B	Washer	4
10B	Breake steal cable	1
11B	Handle	1
12B	Hex screw	4
13B	Brake brib	1
14B	Bolt	4
15B	Transmission holder	1
16B	Rubber cap	1
17B	Oil pipe connector	1
18B	General inlet pipe	1
19B	Check valve	2
20B	Safety locking pin	1
21B	Retaining ring	6
23B	Scissor pin	2
24B	Scissor outside	1

ITEM	DESCRIPTION	QTY
25B	Scissor inside	1
26B	Wheel pin	2
27B	Big wheel	2
28B	Small wheel	2
29B	Wheel pin	2
30B	Conecion pin	2
31B	Cylinder pin	2
32B	Safety locking pin	1
33B	Bolt	1
34B	Nut	1
35B	Cylinder assembly	2
36B	Safety locking assembly	1
37B	Retaining ring	2
38B	Saddle holder	4
39B	Rubber saddle	4
40B	Locking nut	4
41B	Washer	4
42B	Plate	4
43B	Bolt	4
44B	Ring	2
45B	Wheel	2
46B	Nut	2


* Easily Worn Parts



TX MR6K-48

KERNEL ITEM NO. 161202

Kernel Edition 1.0
Mar.2008



Spare Parts List

ITEM	DESCRIPTION	QTY
1C	Pin	1
2C	Spring	1
3C	Lock block	1
4C	Lock pole	3

* Easily Worn Parts

ITEM	DESCRIPTION	QTY
5C	Lock wheel	1
6C	Nut	1
7C	Bolt	1
8C	Steel wire cable	1

ITEM	DESCRIPTION	QTY
9C	Lock sheath	1
10C	Washer	1
11C	Bolt	1
12C	Check valve	1